



ANTENNA EXPERTS

E-mail: info@antennaexperts.in Website: www.antennaexperts.in

Model JC3-2530 2500 – 3000 MHz. 3 dBi. Gain

INSTALLATION MANUAL – OMNIDIRECTIONAL JAMMER COLLINEAR ANTENNA

NOTICE:

Installation, maintenance or dismantling of the antenna system requires qualified and experienced personnel. Antenna Experts antenna Installation instructions have been prepared and are meant for skilled personnel only.

Antenna Experts disclaims any liability or responsibility as a result of improper or unsafe installation practices.

MATERIALS:

Following materials are used for the fabrication of Antennas and its accessories.

Support pipe:	6063T6 Aluminum.
Radiating Elements:	Brass
Radome:	Fiberglass
Mounting Hardware:	All stainless steel.
Fasteners:	All stainless steel.
Connector:	Silver plated brass body & Gold plated pin.
Insulator:	TEFLON.

PACKING LIST

<u>Sl. No.</u>	<u>ITEM/DESCRIPTION</u>	<u>QUANTITY</u>
1.	Fiberglass Jammer Collinear Antenna Complete in assembled condition.	1 Each.
2.	Mounting Hardware (fixed on N connector) to Mount the Antenna.	1 Each.
3.	Installation Manual.	1 Each.
4.	Test Report.	1 Each.

INSTALLATION INSTRUCTION:

1. Unpack the Collinear antenna and mounting hardware from the packing box and remove the plastic sleeve/tube from the fiberglass radome.
2. Antenna should be installed at the maximum possible heights to get the longer communication/jamming area. Even a few Inches of increase in antenna height will results better coverage.
3. A 16 mm hole is required to drill through the roof of the vehicle to mount the Jammer Collinear Antenna on the rooftop of the vehicle.
4. Insert the Jammer Collinear Antenna through the rooftop hole and tighten the supplied nut with split/spring washer against the roof of the vehicle.
5. The mounting clamps to mount the antenna on 25 to 52 mm O.D. vertical round pipe can be supplied on request in case of rooftop hole mounting is not required.
6. Take extreme care during Installation that the Fiberglass portion of antenna must be clear/above from any metallic structure like mounting pipe/mast.
7. Connect the antenna feeder cable to the N-Female connector (provided at the bottom) of the Jammer Collinear Antenna.
8. Seal the connector against moisture ingress with a sealing tape in case of open weather installation.
9. Take VSWR reading by using through-line RF Power meter. The VSWR should never increase 1:2.
10. Keep the record of VSWR measurements for future reference.
11. Tighten all nuts and bolts.